

BlackBerry Wireless Handheld™ Getting Started Guide



- Roll the trackwheel to move the cursor and highlight items on the screen.
- Click (press) the trackwheel to view the menu on most screens and to select items on the screen.
- Press the Escape button to exit a screen, cancel an action, or go back one page in the browser.
- Hold the Escape button to end a phone call.

Tips

Phone

- Open the phone screen Press the **Phone** button
- End a call from the Active Call screen Hold the **Escape** button
- Mute a call from the Active Call screen Press the **Phone** button
- Change the volume during a call Roll the trackwheel
- Dial a letter in a phone number Press **☎** + the letter key
- Call voice mail Hold **☎**
- Assign speed dial to a letter Hold the letter
Type a phone number.
- Type a phone number extension Press **☎** + **☎**
Type the extension number.
- Mute a call using a headset Press the headset button
- End a call using a headset Hold the headset button

Browser

- Open the home page Press **⌂**
- Open the Browser Bookmarks screen Press **🔖**
- Add a bookmark Press **🔖**
- Refresh a web page Press **🔄**
- Search a web page Press **🔍**
- Page down Press the **Space** key
- Go back a page Press the **Escape** button
- Stop a web page from loading Press the **Escape** button
- Go to a specific web page Press **🔍**
- Exit the browser Hold the **Escape** button

Messages

- Compose from the messages list Press **✉**
- Reply to sender Press **↩**
- Reply to all Press **↪**
- Forward a message Press **➡**
- Go to the next date Press **➡**
- Go to the previous date Press **⏪**
- Go to the next unread message Press **📧**
- View sent messages Press **☎** + **📧**
- View received messages Press **☎** + **📧**
- View SMS messages Press **☎** + **📧**
- View voice mail messages Press **☎** + **📧**
- Page up in an open message Press **☎** + the **Enter** key
- Page down in an open message Press the **Enter** key

Calendar*

- Change to Agenda format Press **📅**
- Change to Day format Press **📅**
- Change to Week format Press **📅**
- Change to Month format Press **📅**
- Go to the next day, week, or month Press **➡**
- Go to the previous day, week, or month Press **⏪**
- Go to the current date Press **📅**
- Go to a specific date Press **📅**

*In calendar options, set the **Enable Quick Entry** field to **No** to use these shortcuts in Day format.

©2004 Research In Motion Limited. All Rights Reserved. The BlackBerry and RIM families of related marks, images, and symbols are the exclusive properties of, and trademarks of, Research In Motion Limited (RIM). All other brands and marks are the properties of their respective owners. IBM, Lotus, Domino, and Lotus Notes are trademarks of International Business Machines Corporation in the United States, other countries, or both. Intel is a registered trademark of Intel Corporation or its subsidiaries in the United States and other countries. Microsoft, Outlook, and Windows are registered trademarks of Microsoft Corporation in the United States and/or other countries. The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Research In Motion Limited is under license. There are no warranties, express or implied, with respect to the contents of this document, and all information provided herein is provided "as is". In no event shall RIM or its affiliates be liable to any party for any direct, indirect, special, or consequential damages in connection with your use of this document, including, without limitation, loss of business revenue or earnings, lost data, damages caused by delays, lost profits, or a failure to realize expected savings, even if RIM was expressly advised of the possibility of such damages. RIM reserves the right to periodically change information that is contained in this document; however, RIM makes no commitment to provide any such changes in a timely manner or at all. Your handheld might vary from the depictions on this document.

Published in XXXXX.
PRINTSPEC-005
MAT-07771-001
Model numbers: R6030GE, R6030GN



Navigating your handheld



- Lock the handheld** Set a password > Click **Lock**.
- Lock the keyboard** Click the **Keyboard Lock** icon (only available if you have not set a password)
- Move the cursor** Roll the trackwheel *or* Press + roll the trackwheel
- Return to previous screen** Press the **Escape** button
- Click an item** Highlight the item > Click the trackwheel
- Select multiple items** Hold + roll the trackwheel
- Go to the top of a screen** Press
- Go to the bottom of a screen** Press
- Turn on/off the handheld** Hold
- Turn on/off backlighting** Press

Typing and editing



- Capitalize a letter** Hold the letter
- Insert a period** Press twice
- Type the alternate character on a key** Press + the key
- Insert an accented character** Hold a letter + roll the trackwheel
- Insert a symbol** Press > Click a symbol *or* press a letter
- Select text** Press > Roll the trackwheel
- Select characters** Hold > Roll the trackwheel
- Copy selected text** Press + click the trackwheel *or* Click the trackwheel > Click **Copy**
- Paste selected text** Press + click the trackwheel *or* Click the trackwheel > Click **Paste**
- Cut selected text** Press + *or* Click the trackwheel > Click **Cut**
- Cancel selection** Press the **Escape** button

How do I...

- Make a phone call**
 - In the phone, type a phone number.
 - Click the trackwheel.
 - Click **Call**.
 - To end the call, hold the **Escape** button.
- Add a contact**
 - In the address book, click the trackwheel.
 - Click **New Address**.
 - Type contact information.
 - Click the trackwheel.
 - Click **Save**.
- Send a text (SMS) message**
 - In the messages list, click the trackwheel.
 - Click **Compose SMS**.
 - Click **[Use Once]**.
 - Click **SMS**.
 - Type the SMS-compatible phone number.
 - Click the trackwheel.
 - Click **Continue**.
 - Type a message.
 - Click the trackwheel.
 - Click **Send**.

- Send an email message**
 - In the messages list, click the trackwheel.
 - Click **Compose Email**.
 - Click **[Use Once]**.
 - Click **Email**.
 - In the **Email** field, type an email address.
 - Click the trackwheel.
 - Click **Continue**.
 - In the **Subject** field, type a subject.
 - Press the **Enter** key.
 - Type a message.
 - Click the trackwheel.
 - Click **Send**.
- Set a password**
 - In the handheld options, click **Security**.
 - Set the **Password** field to **Enabled**.
 - Set the other fields on the screen (optional)
 - Click the trackwheel.
 - Click **Save**.
 - Type a password.
 - Press the **Enter** key.
 - Type the password again.
 - Press the **Enter** key.

Wireless network coverage

To turn the wireless radio on or off, click **Turn Wireless On/Turn Wireless Off**.

Wireless coverage

No wireless coverage


Emergency calls

	GPRS	GPRS	GSM
Emergency calls	●	●	●
SMS messages	●	●	●
Phone	●	●	●
Email and PIN messages	●		
Browser	●		

Status indicators

- battery power
- low battery power
- charging
- roaming
- Home Zone
- receiving data
- transmitting data
- service book waiting
- alarm set
- TTY TTY enabled
- voice mail message
- Number lock on
- Shift lock on
- Alt mode on
- Bluetooth radio on
- Bluetooth connected


Fields



Press the **Space** key to change the value in a field.

Press the **Alt** key to view all the values that are available in the selected field.

Menus



Click the trackwheel to view the menu.

On the menu, click standard actions such as **New**, **View**, **Edit**, **Delete**, **Save**, **Options**, and **Help**. Additional options might appear depending on the item you have selected.