


Motorola V300

Getting Started and Accessories Guide



KNOW YOUR MOTOROLA V300


Turn on/off phone:

- Press and hold 

Answering a call:

- Open phone or press 

Making a call:

- Dial a number and press 

End a call:

- Close phone or press 



QUICK TIPS

- To return to the 'idle display' press 'End' Key

GETTING ACCESSORIZED²

Get Moving
Retractable Self Install Hands Free Car Kit



Get Audio
MP3 Player






Get Power
Desktop Charging Stand with Clock




Get Hands-Free
Retractable Headset



STORE A PHONE NUMBER

- Enter a number as if making a call and select **STORE** 
- Select **CHANGE** to enter contact name using keypad
- Change name
- Press **OK** using 
- Press **DONE** using 

PERSONALIZE YOUR FEATURES


- From the idle display press  in any direction and the following four menu features will appear:







- or simply press **MENU**

- These menu icons remain hidden on the idle display but can be programmed to appear at all times.
- Menu icons appearing on the idle screen can be changed to suit your needs and feature preferences. Press **Menu > Settings > Personalize > Home Screen > Home Keys**
 - Press **CHANGE** to make your choice.





DOWNLOAD A GAME¹

- Press **MENU > Web Access > Browser**
- Scroll  to **GET GAMES** and press **SELECT**
- **SELECT Download Games > By Category**
- Scroll to favorite category and press **SELECT**
- **SELECT** favorite game
- **SELECT Buy > Download**






CHANGE YOUR WALLPAPER OR SCREENSAVER

- Press **MENU > Settings > Personalize > Wallpaper or Screensaver**
- Press **CHANGE** 
- Scroll  to preferred picture
- Press **SELECT**  to choose picture
- Press **END** 

TAKE A PICTURE

- Open phone and press **CAMERA** 
- Point camera lens at the photo subject
- Press  to zoom and adjust brightness (optional)
- Press **CAPTURE** to take picture
- Press **STORE**  to save the photo or apply as any of the following: wallpaper, screensaver, phonebook entry, or send in a message
- **SELECT** store options using 

SEND A MESSAGE AND PICTURE USING MMS¹

- Press **MENU > Messages > Create Message**
- Select **New Multimedia Message** using 
- Use the keypad keys to enter text
- When ready to insert a picture press the **MENU** key to open **MMS** menu and select **INSERT** using 
- **SELECT** picture
- Scroll to the picture file and press **SELECT** using 
- Add heading using keypad keys and press **OK** 
- Scroll  to select message recipient and select **ADD**
- Press **DONE**
- Press **SEND**

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. All other product or service names are the property of their respective owners. The Bluetooth trademarks are owned by their proprietor and used by Motorola, Inc. under license.

¹ Network and subscription dependent feature. Not available in all areas.
² Optional accessories are sold separately.